



## Special lubricant

## **AUTOL ZAHNRADSPRAY**

CFC free

Special lubricant for versatile use.

**AUTOL ZAHNRADSPRAY** is a lubricant with solid lubricants, extreme pressure additives, adhesion additives and corrosion inhibitors.

The dry lubricating film has a wear- and noise-reducing effect, is non-slip and flexible, does not attract dust and dirt and is resistant to water (including sea water).

Due to the solid lubricant content in **AUTOL ZAHNRADSPRAY**, emergency running properties are given up to 300°C.

Before applying the lubricant for the first time, the lubrication points must be cleaned down to the bare metal. Renewal of the lubricating film is only necessary when the bare metal becomes visible again.

Possible uses:

**AUTOL ZAHNRADSPRAY** can be used to lubricate open gears, racks, ring gears, slideways, drive chains or wire ropes.

Apply **AUTOL ZAHNRADSPRAY** sparingly and only start operation when the solvent has evaporated. The service temperature is between -20°C and +50°C.

When selecting the product, the manufacturer's instructions must be observed.

Enilive Schmiertechnik GmbH Paradiesstraße 14 97080 Würzburg Tel. 0931 90098-0 e18900